



www.acetk.com

\*All the specifications and contents in this manual are subject to change without notice.  
\*All the specifications and contents are only for reference, please make the object as the standard.

## •Description

1. The Lighter S, is a smallest and lightest tracer unit designed for the pistol.
2. Because of its small dimension, it enables users easily to install it into their silencers or airsoft gun hand-guards as long as their inner space is larger than the dimension of Lighter S. (Diameter: 27mm or 1.06 inches, length: 67.3mm or 2.65inches)
3. Lighter S could light up green tracer BBs with very high brightness but lighten red tracer BBs with medium brightness.
4. Do not disassemble the Lighter S to prevent high voltage electrical shock.
5. It automatically switches off under the following conditions:
  - A. Device has idled for 40 minutes
  - B. When the battery power is low, after the power indicator blinks in red color for 3 seconds.
6. Remaining power indicator (flash once per second)
  - A. Green light: high power
  - B. Orange light: medium power
  - C. Red light: low power
7. Do not look straight into the muzzle to check the installation of the device to prevent any accident like mistakenly pulling the trigger or firing the gun.
8. In order to extend the built-in Li-Poly battery life as much as possible, please charge it least once every 2 months.

## •Instruction

- 1.Should charge the Lighter S before using it the first time. Please refer to the following steps:
  - A.Unscrew the front cap by turning counterclockwise to open the Lighter S.
  - B.Insert one end of the MicroUSB charging cable into the Lighter S and the other end into the charger.



- C.The charger indicator would light on to indicate that the Lighter S is charging now.



- 2.When the Lighter S is fully charged, the charging indicator would light off. Pull out the charging cable and then screw the front cap by turning clockwise to close the device.
- 3.Install the Lighter S in front of the muzzle.
- 4.Press the power button and then the power indicator will blink (once per second).
- 5.The Lighter S would turn off automatically after leaving it idle for 40 minutes.
- 6.When not in use, press the button power to turn off the Lighter S as well as the power indicator.
- 7.The following situations indicate that the battery is dead and needs charging:
  - A.You could not turn on the Lighter S.
  - B.You could turn on the Lighter S but the power indicator is in red light, flashes quickly a few times and then it turns off.

## •Specifications

- ※ Supports green tracer BBs.
- ※ Supports up to 35PRS.
- ※ Built-in li-Poly battery, Charging time: 2.5 Hours.
- ※ Accessories:
  - ▶ MicroUSB charging cable x 1,
  - ▶ Adaptor x 1 (M14 anti-clockwise thread to M11 clockwise thread)
- ※ Fully charged battery would last over 22000rounds.
- ※ Led power indicator / battery power indicator
- ※ FCC, CE, ROHS compliant
- ※ Dimension: Diameter: 27mm (1.06 inch), length: 67.3mm (2.65 inch)
- ※ Weight: 32g (without adaptor)