


## LOADING MAGAZINE





# **LOADING OPREATION & LOAD INDICATOR**




## SWITCH FIRE MODE

#### SAFE MODE:


• FLIPSWITCH TOWARD THE REAR

#### FIRE MODE:


• FLIP SWITCH TOWARD THE FRONT



### TO SHOOT




# **HEXKEYS**




## HOP-UP ADJUSTMENT

- USE A HEX KEYTO ADJUST HOP-UP
- DAIL CLOCKWISE FOR MORE HOP-UP
- DAIL COUNTER-CLOCKWISE FOR LESS HOP-UP



### PRODUCT FEATURES



### SPECIFICATIONS -

**POWER SOURCE:** SPRING BOLT ACTION (CO2 & GAS OPTIONAL) LENGTH:

1085mm

2610g 55rounds SAFE / FIRE MAGAZINE CAPACITY: FIRE MODE:

WEIGHT:

METAL + NYLON FIBER MATERIAL:

HOP-UP: **ADJUSTABLE** 

## **SAFETYINSTRUCTIONS**

#### EAD ALL INSTRUCTIONS BEFORE USE!

FOR ADULT USE ONLY. NOT TO BE OPERATED BY MINORS UNDER THE AGE OF 18.
 NEVER MODIFY OR ALTER YOUR AIRSOFT GUN. Attempts to modify the airsoft gun in any way could make your airsoft gun unsafe to use, cause serious injury or death, and will

void the warranty.

Misuse of Airsoft Guns is dangerous and can cause serious injury or death. Always treat an
Airsoft gun with the same respect you would towards a real firearm.

#### **SAFETY CONSIDERATIONS**

- NEVER look into the gun's muzzle
  NEVER point the Airsoft gun at anything you do not intend to shoot.
  NEVER shoot at targets that may cause the BB to bounce off, such as hard surface that
- could produce a ricochet.

   ALWAYS ensure the operator and everyone nearby are wearing appropriate eye protection

   ALWAYS ensure the fire-selector is on "SAFE" until you are ready to shoot.

   ONLY shoot the airsoft gun in designated area, towards a safe direction, using



#### **GENERAL PRECAUTIONS**

- with a real firearm.

  This merchandise cannot accept firing components from a real firearm, nor be able to chamber / fire real ammunition.

  This merchandise is designed to function solely with 6mm airsoft ammunition.

  ONLY use high-quality precision plastic BBs designed for 6mm Airsoft guns.

  NEVER reuse a BB that is dirty, has been shot from the gun, or otherwise deformed. Use of contaminated or imperfect BBs could damage your gun.

  ALWAYS transport Airsoft guns in it's original box or an appropriate gun case.
- NEVER carry the gun in plain sight.

   ALWAYS store the airsoft gun unloaded, and out of reach by children.
- Using unauthorized repair centers or modifying the function of your airsoft gun in any way
  may be unsafe and will void your warranty.
- The manufacturer, distributors, and retailers are not liable for any malfunction accidents, injuries or repair cost resulting from misuse, or by disassembly and modification of the airsoft gun.

