www.aps-concept.com **CO2 PISTOL** TTi-Custom **USER MANUAL**

CO2 PISTOL MODEL: TTi-Custom



OVERALL PARTS 01





PLEASE READ THIS MANUAL COMPLETELY. REMEMBER TO TREAT THIS AIRSOFT WITH THE SAME RESPECT AS A FIREARM. ALWAYS CAREFULLY FOLLOW THE SAFETY INSTRUCTIONS FOUND IN THIS MANUAL AND KEEP IT IN A SAFE PLACE FOR FUTURE USE.

CO2 PISTOL MODEL:TTi-Custom



MAGAZINE PARTS



Optional **End Cap**

New 1 Step

CO2 INSTALLATION : STEP 1

Insert the 12gm CO2 up-side down and screw back the switch end-cap.



Turn the whole end cap clockwise by an 6mm Allen Ke Turn all the way down, wait 1 minute for gas to fill up the ma



LOADING BBs

CO2 PISTOL

MODEL : TTi-Custon

- Load BB bullet in the magazine, 6mm (23+1 rounds only)
- Please follow the illustrative sequences to load the BB bullets.



While loading the magazine, push it inward to the bottom till a "click"sound



Press the magazine release catch to unload the magazine.

CO2 PISTOL MODEL : TTi-Custom

▲ MISS HANDLE THE AIRSOFT MAY CONDITION SERIOUS INJURE OR DEATH. PLEASE READ THE SAFETY INSTRUCTION BEFORE USE.

CO2 PISTOL

MODEL: TTi-Custom



IRST LOAD & FIRING

Pull the slide backward to a specific position, then release the slide forward to load the bullet in the

FIRST LOAD & FIRING

When the chamber is load, press the trigger to fire.




Grasp the pistol with the thumb under the backstrap and the remaining four fingers on the top of the slide. Squeeze your hand like you are making a fist so the slide comes back While holiding the slide to the rear.

DISASSEMBLY : STEP 2

DISASSEMBLY: STEP 1

to release the magazine.

Engage the magazine release catch



CO2 PISTOL

MODEL : TTi-Custom



DISASSEMBLY : STEP 3

Pull the slide backward and then push all the way forward until it separated from the receiver.Ø

CO2 PISTOL MODEL: TTi-Custom

COMPROMISE IS NOT AN OPTION

WARNING: OBSERVE SAFE AIRSOFT HANDLING PRACTICES AT ALL TIMES. FAILURE TO DO SO MAY RESULT IN SERIOUS BODILY INJURY OR DEATH, APS LIMITED SHALL NOT BE RESPONSIBLE FOR INJURY, DEATH, OR PROPERTY DAMAGE RESULTING FROM FAULTY INSTALLATION. MISUSE, ILLEGAL USE, OR MODIFICATION OF THIS PRODUCT.



www.aps-concept.com Manufactured & Distrubted by APS LIMITED 4/F, Wing Kwai Fty. Bldg. 2-8 Wang Wo Tsai St, Tsuen Wan N.T. HONG KONG SAR Production by APS Hong Kong Made in China

CO2 PISTOL MODEL: TTi-Custom



SSEMBLY: STEP 4

Pull up on the captured recoil guide-rod assembly and lift it away from the barrel.



SEMBLY : STEP 5

Remove the barrel by pushing it forward so it unlocks from the barrel and then lift it up and out at 45 degree angle from the slide.

CO2 PISTOL MODEL: TTi-Custom



LUBRICATION Once the barrel is cleaned in the manner stated

above, all that it requires is one drop of lubricant in he cam surface and one drop pread around the ocking stepped portion of the barrel hood. Put one drop in each rail and stand the slide up front sight down to let it run the length of the slide rails. Use a small dab of molybdenum grease on the surfaces where surfaces where there is metal-on-metal contact, like the firing pin safety punger and striker heal.

A READ ALL INSTRUDTIONS AND WARNINGS IN THIS MANUAL BEFORE USING THIS AIRSOFT, BUYER AND USER HAVE DUTY TO OBEY ALL LAWS ABOUT THE USE AND OWNERSHIP OF THIS AIRSOFT, THIS PRODUCT IS INTENDED FOR USE BY THOSE 18 YEARS OF AGE OR OLDER.

CO2 PISTOL **MODEL: TTi-Custom**



the Hop up shield wheel towards "HOP".



Increase the Hop effect by turning





Put gun safety in "SAFE"

















When you are ready to fire, point the gun in a SAFE DIRECTION, place the gun safety in "FIRE"

A KEEP THE GUN IN THE "SAFE" POSITION UNTIL YOU ARE ACTUALLY READY TO SHOOT. THEN TURN THE SAFETY TO "FIRE".

CO2 PISTOL MODEL: TTi-Custom

